Click Here

How to adjust the draw weight on a barnett vortex compound bow

The Barnett Vortex is an ideal youth compound bow for starting archery and bowhunting experiences. Its compact design allows for effortless management in the field. Parents can customize their teen's shooting experience with modular adjustments to draw weight and length. The Vortex comes with a 5-year warranty, but only in right-handed versions. To adjust the draw weight without changing the length, use the correct cam module for your desired draw weight. The bow features five modules that enable adjustments between 21-27 inches in half-inch increments. This also allows for about nine pounds of adjustment per turn. For example, using the B module with string on "+" post results in a draw weight of 42.5 lbs. Switching to C module reduces it to 35 lbs. Refer to the manual's adjustment chart to determine the correct module and string position. When changing the string position, a bow press is required. Ensure both cams are on the same post for proper tuning. Using a bow press, select a suitable replacement string as specified in the user manual. Apply wax to prevent slipping during attachment. It's generally safer and less likely to damage the bow when loosening its weight-adjustment bolts by five to seven turns beforehand. Place the bow into a bow press, as this will provide better support for the bow. Before putting the bow in the press, loosen the limb bolts on each side of the bow separately, alternating between them to avoid applying unequal pressure on the bow. This step may vary slightly depending on the specific bow press model you're using. Determine whether or not it's necessary to remove the old string from your compound bow. If it has a teardrop attachment point with two grooves for the string, you should attach the new string while keeping the old one in place. For bows without this type of attachment, remove the old string first by unhooking it from each cam or idle wheel at the end of each limb. Next, attach the new string to your bow according to its specific design. If your bow has a teardrop attachment point, you should attach the new string to the empty groove while the old string is still in place. After that, remove the old string. For bows without a teardrop attachment point, start by attaching one end loop of the new string to the appropriate post at the center of one cam. Then, loop the string under and back over the cam, making sure it fits into the groove. Repeat this process on the other cam if your bow has two cams. Once you've finished attaching the new string, tighten the bow and take it out of the press. Next, re-tighten the bolts back to their original settings, again alternating between the limbs with each turn. As you slowly release the bow from the press, make sure that the new string is properly seated in its correct grooves. To avoid damage when loosening the bolts on your Barnett Vortex compound bow, remember that this is a youth compound bow and has an adjustable draw weight ranging from 16-45 lbs. So, if you're reducing the draw weight, ensure it's not below the minimum recommended hunting weight of 45 lbs. as adjusting the limb bolts could lead to the bowstring or cams breaking. Consult your Barnett Vortex manual for the maximum number of turns allowed on the limb bolts. After adjusting the bolts, secure the locking screws to prevent disengagement during use. Note that some adjustments may require a bow press, such as fine-tuning the draw weight and length. If you don't have access to a bow press, consider taking your bow to a specialist for certain adjustments. It's crucial to make equal adjustments on both limb bolts when setting the poundage. This ensures the limbs remain evenly tensioned, preventing unbalanced performance and potential damage. To adjust the poundage, turn the limb bolts clockwise or counter-clockwise in small increments, with no more than three full turns per bolt. Ensure equal turns on each bolt to maintain balance. By making equal adjustments, you can fine-tune the poundage of your Barnett Vortex compound bow to suit your needs. This allows for customization based on strength and skill level, ensuring a comfortable and accurate shooting experience. Always exercise caution when adjusting the poundage and never exceed recommended turns to avoid potential damage. The adjustable draw weight of the Barnett Vortex, ranging from 16 lbs to 45 lbs, is an essential feature for young archers. This adjustability ensures comfort, safety, and accuracy as they grow stronger and gain more experience in archery and bowhunting. Making adjustments to the Barnett Vortex's draw weight requires specific tools and careful procedures, as excessive alterations can lead to a loss of balance and safety issues. Typically, adjusting the draw weight involves locating the limb bolts on the upper and lower limbs near the riser and using an Allen wrench to rotate these bolts. However, in some cases, particularly when significant changes are needed or when dealing with specific bow designs, utilizing a bow press may be necessary. For instance, changing the string position on the cams of the Barnett Vortex necessitates the use of a bow press. It is crucial to adhere to the manufacturer's guidelines, employ the correct tools, and implement gradual adjustments to avoid damaging the bow or compromising safety. Even if you're comfortable making these changes yourself, consulting a professional bow technician can be beneficial in ensuring your bow functions optimally. Find the limb bolts on your compound bow by looking near the center, where they attach the arms (limbs) to the main body (riser). These bolts control how much tension is put on the string when you draw the bow. The riser is the central part of the bow that holds all the mechanical parts together. Next, locate and loosen any locking screws or bolts on either side of the limb bolts. These keep them in place once adjusted, so loosen them to make adjustments. Use an Allen wrench (usually provided with the bow) to turn these bolts. Tighten one bolt a little at a time to add weight, loosen for less tension. Make sure both arms have the same amount of weight. Remember, one full rotation usually adds about 1.5 pounds. Now, test how it feels to draw the string back by holding the bow as you normally would and pulling back the string. If it's too heavy, make adjustments until it feels right – like drawing in one smooth motion. The ideal draw weight is what your upper body strength can handle comfortably. It shouldn't feel too hard or impossible to keep drawing after several shots. A light draw weight is easier but might mean less force for your shot. Don’t forget how important the type of arrow you’re using is, as it affects how strong and straight your shot will be. Also remember to consider your draw length when setting your bow's tension – this is how far back you can pull the string before releasing. This affects how much power you can use on each shot. The weight of your bow matters! A longer draw length puts more stress on both you and the bow. Make sure it's tailored to your body size by having a pro adjust it if needed. Your arm span should match the bow's draw length, which is trickier to change than you think. Think about how you'll use the bow – for hunting, competitions, or just fun. Hunters like heavy pulls for stronger arrows, while competition archers want lighter weights so they can shoot without getting tired. There are different bows for each kind of user. Pick a weight that feels comfy in your hands. Don't let ego lead you to a heavier bow than you're ready for. Adjust until it's easy to draw, hold, and release the string. It might take some trial and error, but with practice, you'll get more accurate shots. If you're new, use average weights as a guide – kids start around 20-30lbs, women under 170lbs are around 30-40lbs, and men over 200lbs can go up to 100lbs. Try different sizes and weights until you find what works best for you. These are just averages, though – the best bow weight is one that feels right to you. When testing a new draw weight, pull the string back and hold it for about ten seconds. If you start straining or can't keep it drawn, loosen the limb bolts a bit at a time until it's more manageable. You should be able to hold the string taut without struggling for a few moments. When drawing back the bowstring, it's called the "wall." To calculate the perfect amount of tension for a shot, you can use this concept. Drawing and holding the bow is an exercise that helps you get used to aiming while shooting. It's helpful to practice with your feet off the ground. To do this test, sit in a chair and hold the bow in front of you as if sighting a target. Now, pick your feet up and hold them as you pull back the bowstring. This makes it harder to stay stable, so you can see how much you're relying on your shoulders and back. If you find that holding your feet off the ground gives you too much control, know that when you have your feet on the ground, the upper body plays a smaller role in drawing. When pulling back the bowstring, note where it feels heaviest. Normally, this is right before reaching the wall. If the resistance starts early or the draw feels too fast, you might need to adjust the limb bolts to get a smoother pull. Your draw should be one smooth movement without any slowdowns. Properly gripping a compound bow is crucial for optimal accuracy and comfort during use. To achieve this, hold the bow with your thumb resting on the fleshy area at its base, where it seamlessly transitions into your palm. Ensure the pressure flows directly up your arm and through your shoulders, maintaining a straight alignment. Avoid bending your wrist in any direction. This grip provides optimal structural support, requiring minimal muscle effort to hold the bow at full draw. Thanks a lot!